	Logistics Solutions & Compliance Technical Assessment 2020TA022 v2.0	Page 1 of 2
	Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper	CONFIDENTIAL

1. Purpose

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper with version control.

2. Appendices


Appendix ID	Title
Appendix A	Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

3. Change History

Issue Number	Description of Change(s)	Reason for Change(s)
1.0	Initial Release	Initial Release
2.0	Updated formatting and pictures for clarity.	Updated formatting and pictures for clarity.

4. Approvals:

Logistics Solutions and Compliance Transport Qualification and Compliance Manager				
Author:	Name	5.1.2e	Sign/Date	5.1.2e 21 Oct 2020 18:48:024-0400 REASON: I approve this document as author. 0a1fb5f4-f692-45e0-8d06-8eb5d9529e8f
Logistics Solutions and Compliance Sr. Manager Transport Validation & Innovation				
Approved:	Name	5.1.2e	Sign/Date	5.1.2e 21 Oct 2020 19:10:029-0400 REASON: I approve this document. 524412a2-6820-4b64-8cc4-a43540e06a26

	Logistics Solutions & Compliance Technical Assessment 2020TA022 v2.0	Page 2 of 2
	Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper	CONFIDENTIAL

Appendix A: Instructions
(11 Pages)

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

Table Of Content

1. Purpose	2
2. Scope	2
3. Reference Documents	3
4. General Requirements	3
4.1. Materials	3
4.2. Recommendations	3
5. Procedure	4
5.1. Unpackaging	4
5.2. Re-Icing	7
6. History of changes	10
7. Appendix	11
7.1 Appendix 1: AeroSafe 47L7 ULT Parcel Shipper	11

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

1. Purpose

The purpose of this controlled document is to provide unpackaging and re-icing requirements on the AeroSafe 47L7 Parcel Shipper with Dry Ice.

CAUTION: Use of dry ice in confined spaces (small rooms or walk-in coolers) and/or poorly ventilated areas can result in depletion of oxygen resulting in asphyxiation. Exposed skin should be protected from contact with dry ice. Eye protection is recommended (for example, safety glasses).

Appropriate training to be been conducted for personnel handling dry ice and documented within their relevant training system as required.

2. Scope

This controlled document is applicable to unpackaging and re-icing requirements using the AeroSafe 47L7 ULT Parcel Shipper with Dry Ice.

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

3. Reference Documents

Document Number	Description
N/A	Safe Handling Guidelines for Dry Ice
N/A	Safety Data Sheet Dry Ice

4. General Requirements**4.1. Materials**

Specification Number	Description
CD-86218	SPEC – AeroSafe 47L7 Small Parcel Shipper
N/A	Insulated (Thermal) Gloves
N/A	Safety Glasses
N/A	Carton Sealing Tape
N/A	Dry Ice Pellets (10 to 16 mm)

4.2. Recommendations**Recommendations (Using Thermal Shipping Container as Temporary Storage)**

- The thermal shipping container is a passive (non-compressor) device that contains dry ice as the energy source to maintain the required temperatures when maintained properly as defined by Pfizer instructions. The dry ice in the thermal shipper will deplete over a number of days (duration will vary depending on use and care), which will impact how long the shipper holds the temperatures. This differs from an ultra-low-temperature freezer, an active (electronically powered, compressor-driven) device, which when plugged in, is designed to maintain ultra-low temperatures indefinitely. The longer the thermal shipping container remains closed, the longer it will take for the dry ice to deplete.
- The thermal shipping container should be stored at 15° to 25° Celsius, which is 59° to 77° Fahrenheit.
- The thermal shipping container is qualified with a minimum of 22 kgs of dry ice pellets (10 mm – 16 mm pellets). Upon receipt and after opening, the box should be replenished/inspected with dry ice within 24 hours by adding dry ice to the maximum within the payload insert areas and dry ice pod.
- The thermal shipping container should be re-iced every 5 days.
 - This can help maintain the level of dry ice and the temperature of the vaccine product. It is recommended that the thermal shipping container not be opened more than 2 times a day, and shouldn't be opened for more than 1 minute at a time. If that is followed, the thermal shipping container should then be re-iced every 5 days.

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper



Recommendations (Using Thermal Shipping Container as Temporary Storage)

- Local dry ice suppliers should be used for re-icing the thermal shipping container.
- Temperature monitoring devices to be used if thermal shipping container is used as temporary storage. Sites are responsible for obtaining their own temperature monitoring devices to monitor temperatures when using the thermal shipping container as temporary storage. Temperature monitoring devices (probe or probeless) capable of being in a dry ice environment to be used and placed in the location of the vial tray payload area within the thermal shipping container.
- The thermal shipping container should be returned within 20 business days of delivery, including temperature data logger.
 - If you receive a Controlant Real-Time Temperature Monitor, it must be returned with the thermal shipping container.
 - If you receive a Sensitech Temperature Monitor, it does not need to be returned.



5. Procedure**5.1. Unpackaging**

Responsible Role	Action Step
Operator	1. Before opening the thermal shipping container, make sure the area in which you are working has proper ventilation. Use of dry ice in confined spaces, such as small rooms, walk-in coolers, and/or poorly ventilated areas, can result in depletion of oxygen, resulting in asphyxiation.
	2. In a well-ventilated area, open the Outer Corrugated Shipper by cutting the tape on the outside.

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

Responsible Role	Action Step
	
	<p data-bbox="560 1200 1302 1308">3. Remove the VIP Lid carefully as the temperature monitor probe is connected to the Payload Box. Care should be taken to not disconnect the probe from the Payload Box.</p> 
	<p data-bbox="560 1704 1302 1776">4. While wearing insulated (thermal) gloves, take out the Dry Ice Tray.</p>


Unpackaging and Re-icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

Responsible Role	Action Step
	
	<p>5. Remove the Payload Box from the thermal shipper by carefully pulling directly upwards. Care should be taken to not disconnect the probe from the Payload Box.</p> 
	<p>6. Open the Payload Box and remove the vial tray.</p>
	<p>7. Take out the product for inspection and immediately (within one minute of opening) store in an ultra-low temperature freezer or prepare for use. If shipper will be used as temporary storage for remaining vials within tray, immediately re-insert the tray with vials within one minute of opening and follow the re-icing instructions.</p> <p>*Refer to Recommendations section of this procedure for further details on using the thermal shipping container as temporary storage.</p>
	<p>8. If not using the thermal shipping container as temporary storage, insert all components back into the thermal shipping container for return.</p>

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

Responsible Role	Action Step
	<p>Dry ice must be discarded in a well ventilated area before considering returning the thermal shipping container.</p>

5.2. Re-Icing






Responsible Role	Action Step
Operator	<ol style="list-style-type: none"> 1. Before opening the thermal shipping container, make sure the area in which you are working has proper ventilation. Use of dry ice in confined spaces, such as small rooms, walk-in coolers, and/or poorly ventilated areas, can result in depletion of oxygen, resulting in asphyxiation. 2. In a well-ventilated area, open the Outer Corrugated Shipper by cutting the tape on the outside.

Unpackaging and Re-icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

Responsible Role	Action Step
	
	<p data-bbox="560 1200 911 1234">3. Remove the VIP lid, Item A.</p> 
	<p data-bbox="560 1592 1303 1697">4. While wearing insulated (thermal) gloves, take out the Dry Ice Tray, Item B as required to get better access to the Scaffolding to begin re-icing.</p>
	<p data-bbox="560 1733 1273 1800">5. Fill the Scaffolding, Item D of the shipper with dry ice to the top of the scaffolding.</p>

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

Responsible Role	Action Step
	<p data-bbox="560 389 1262 456">6. Reinsert the Dry Ice Tray, Item B on top of the Payload Box, Item C. Fill the Dry Ice Tray, Item B with dry ice to the top.</p> 
	<p data-bbox="560 893 1098 925">7. Add the VIP Shipper Lid, Item A back on top.</p> 
	<p data-bbox="560 1341 1283 1373">8. Fold the outer corrugated flaps and reseal shipper with tape.</p> 

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

6. History of changes

Version	History of Changes
01	Initial version
02	Updated formatting and pictures for clarity.

Unpackaging and Re-Icing Instructions of the AeroSafe 47L7 ULT Parcel Shipper

7. Appendix

7.1 Appendix 1: AeroSafe 47L7 ULT Parcel Shipper

Note: Approximate weights are based on maximum configuration of dry ice.

ITEM	DESCRIPTION
1	VIP LID
2	DRY ICE TRAY
3	PAYLOAD BOX (Takes 1 vial tray)
4	47L7 THERMAL SHIPPER

Aerosafe 47L7 Weights and Dimension	
Empty Shipper Weight	9.4 kgs
Available Payload Space	9.75" x 9.75" x 9.75"
External Dimension	17.5" x 17.5" x 21.5"
Amount of Dry Ice	22 kgs
Tare Weight w/ Dry Ice	31.4 kgs
Total weight w/ 1 vial tray	32.5 kgs

Weight of Vial Tray	1.038 kgs
---------------------	-----------